

MOMENTA armchairs

Short Stay Seating

Metal frame, Tilting back, Fixed or adjustable armrests

REF. FMMOMIAF2, FMMOMIAR2

AHF[®]

A MEDIUNIC COMPANY

The **MOMENTA2** armchairs have been specially designed for hospitals and healthcare facilities. Robust, customisable and comfortable, the backrest can tilt to an angle of 50°. AHF offers 2 versions: the first has fixed armrests, the second armrests adjustable. Our numerous different fabrics will allow you to match your chairs to the bedroom decoration. Our design department is also on hand to create bespoke versions to your specifications. AHF also designs and makes chairs, carver chairs and footstools and backrests for its customers.

Technical specifications

- BACKREST**
- Reclining backrest adjustable via a bilateral handle
 - Polyether foam covered with fabric: GINKGO (textured) or URBAN (smooth)
 - Customizable fabric (refer to our complete color chart for a wide range of shades)

- STRUCTURE**
- Epoxy-coated tubular frame **RAL 7035** with high admissible load and robustness.

- LEGS**
- Non-marking polyethylene glides with two integrated rear wheels for easy movement of the empty chair.

ARMRESTS

- Polyurethane armrests
- Width 6.7 +/- 1 cm
- REF: FMMOMIAF2
Fixed armrests (19 cm)
- REF: FMMOMIAR2
Armrests adjustable to 4 positions:
0 – 19 – 22 – 25 cm

SEAT

- Polyether foam covered with fabric: GINKGO (textured) or URBAN (smooth)
- **Customisable fabric** (see our colour chart for the numerous colours)



Technical data

Seat height	46,0 cm
Dimensions	
Width	65.5 cm
Height	127 cm
Depth	70,5 cm
Maximum tilt angle	92° to 125°
weight	27 kg
Max. dynamic admissible load	135 kg
Materials	Steel (frame), Fabrics, Polyether foam Polyethylene, Polyurethane
Tubular frame	Diameter 32 mm
Foam density	Seat back: 65 kg/m³ Seat: 65 kg/m³
Fire rating – Anti-fire standard	M1 – Non-flammable

Customisation and Accessories

GINKGO fabrics



* The AHF colours may change (new colours, changes to shades)

URBAN fabrics



- Accessories & Options available**
- Removable headrest

Hygiene & Disinfection

- The fabrics comply with standard NF EN 15973: clean with a pH neutral soap and a soft brush. Clean stains such as pen ink, coffee, etc. immediately to avoid the stain migrating through the coating on the fabric and becoming permanent.
- Cleaning products must be sprayed on or applied with a disposable cloth
- It is also recommended to start cleaning at the top and work down

